
# MINI LED MOVING HEAD

MJ-1005-4IN1



# **User Manual**

# ---PROFESSIONAL STAGE LIGHTING -----

Thank you for choosing our Mini LED moving head light. For the sake of your safety, Please read and follow these instructions carefully and keep this manual in a safe place for future reference.

	113-127	Auto 8
	128-142	Sound 1
	143-157	Sound 2
	158-172	Sound 3
13	173-187	Sound 4
	188-202	Sound 5
	203-217	Sound 6
	218-232	Sound 7
	233-255	Sound 8
14	150-255	Reset

## 12. Technical parameters

Voltage: AC100-240V,50Hz/60Hz Power Consumption: 90 Watts

LED: 4IN1\*7LED

LED Power: 10W (x 7pcs) LED Current: 500mA / 1 pc

LED Beam Angle: 25°

Pan:540° Titl:180°

Operation Modes: DMX512, Manual, Sound, Internal Program,

Master/Slave

DMX Control: 9/14 Channels

Control Panel: Digital 4 Character Alphanumeric

Maximum Ambient Temperature: 40° C

Gross Weight: 3.8 kg

Package Size: 25 x 22 x 29.5cm

7

# Catalogue

	Chapter	Page
1.	Product Illustration	1
2.	Installation	1
3.	DMX connection	1
4.	Maintaining	2
5.	Precautions	2
6.	Warning	2
7.	Difficult processing	3
8.	Declaration	3
9.	Equipment and appendix	3
10.	. Menu display function	4
11.	. DMX function	5
12.	. Technical parameters	7

- ♦ Before open the LED moving head and if you want to do the repair work, please make sure the power source is at the separation condition.
- Unceasingly carries on the product improvement about our company the policy, in this instruction booklet carries the data will have the possibility to be able to change in the future, when no longer separate notice change matters concerned. Our company retains when the product improvement changes the related specification the authority. This instruction booklet publisher cannot be responsible regarding this instruction booklet in information accuracy, also cannot the related consequence which causes regarding these information be responsible.

### 1. Product Illustration

Our product adopt semiconductor to produce radiation, LED as light origin. With advantage of operation quietly, less power waste, high brightness, gaily-colored, astigmatic, high longevity (60-100 thousands hours), non-calorific etc. Our product use 4IN1\*7 LED, synthesize turn colors under election, can create effect of auto gradual change/skip change color, frequent blinking. Can accept control by DMX512, real save power, no pollution green lighting tool.

### 2. Installation

Use the four bolts with M6 size by the clip of the LED moving head to install it. Should guarantee the reliability of the install, this way is to prevent the LED moving head occurs swings and skids when it's working. The weight is about 3Kg of each LED moving head, before install, you should confirm the structure whether can support this weight of the LED moving head light. In order to guarantee the security, you also need to install a safety chain in the lamp body side handle.

## 3. DMX connection

The connection of controller between the led moving head lamp or respectively led moving head lamp should use the twin core shielded cable, and the diameter of each core at least be 0.3mm.

When installing, uses the DMX signal terminal is much better. It can avoid the digital control signal breached by the electrical noise. Generally speaking, the DMX terminal is Cannon plug coupling, it has a 120 ohm resistances between the 2 feet and 3 feet, it will connected on the last led moving head lamp's digital plug of the led moving head lamp chain.

8	0-255	GREEN
9	0-255	BLUE
10	0-255	WHILE
		Color Changing
	0-7	Color Mixing1
	8-21	Color Mixing2
	22-34	Color Mixing3
	35-49	Color Mixing4
	50-63	Color Mixing5
	64-77	Color Mixing6
	78-91	Color Mixing7
	92-105	Color Mixing8
11	106-119	Color Mixing9
	120-134	Color Mixing10
	135-147	Color Mixing11
	148-161	Color Mixing12
	162-175	Color Mixing13
	176-189	Color Mixing14
	190-203	Color Mixing15
	204-217	Color Mixing16
	218-231	Color Mixing17
	232-255	Color Jump Changing
12	0-255	Color Changing Speed
		Auto Running Program
		MOVEMENT(AUTO & SOUND EFFECT)
	0-7	Blank
	8-22	Auto 1
13	23-37	Auto 2
	38-53	Auto 3
	54-67	Auto 4
	68-82	Auto 5
	83-97	Auto 6
	98-112	Auto 7

### 11. DMX function

#### 9CH Mode

CHANNEL		Function
1	0-255	Pan
2	0-255	Tilt
		Dimmer and strobe
	0-7	Null
3	8-134	Dimmer
	135-239	Strobe from slow to fast
	240-255	Lighting Open
4	0-255	RED
5	0-255	GREEN
6	0-255	BLUE
7	0-255	WHILE
8	0-255	Motor Speed
9	150-200	RESET

### 14CH Mode

CHANNEL		Function
1	0-255	Pan
2	0-255	Pan Fine
3	0-255	Tilt
4	0-255	Tilt Fine
5	0-255	Motor Speed
		Dimmer and strobe
	0-7	Null
6	8-134	Dimmer
	135-239	Strobe from slow to fast
	240-255	Lighting Open
7	0-255	RED

# 4. Maintaining

- 1. The fixture should be kept dry to avoid working in wet conditions.
  - 2. Intermittent use will effectively prolong the life of this fixture.
- 3. For a good ventilation and lighting effects, please clean the fans ,fan nets and lens usually .
- 4. To avoid damage this fixture, please don't use alcoholic or other organic solvents to clean the fixture shell.

### 5. Precautions

- 1. In order to ensure the life of this fixture, please don't place this fixture where is moisture or leakage, and don't operate the fixture at temperatures higher than 40°please!
- 2. Don't place the fixture where is easy to loose or vibration-prone
- 3. To avoid risk of electric shock, please ask the professionals to maintain this fixture.
- 4. When connect the fixture to power, the changes of power voltage should be at-10% ~+10%,if higher, will reduce the life of the fixture, but if lower, will effect the lightness.
- 5. Should need 20 Min. to fulling cool the light before re-use.
- 6. In order to ensure the normal use of this product, please read this manual carefully.

# 6. Warning

- ·Don't disassemble and assemble the LED moving head.
- -Please Do not put the led moving head lamp in water or other any types liquids and the metal (IP20).
- •Do not install the led moving head lamp in the humidity environment.
- •Should maintain the minimum 0.5 meter distance between the led moving head lamp and other neighboring object surface.

# 7. Difficult processing

Question	Answer
The LED moving head lamp can	Inspects the fuse on the rear panel.
not start.	
Although shines, but the LED	Check the digital start address (sees
moving head lamp can not accept	09th) and also check the connection
the instruction of the controller.	situation of the communication control
	line the (to see 03rd).
LED moving head lamp only can	Inspect the power supply and voltage is
work intermittently.	whether normal.
Do not receive the DMX512 signal	Whether the signal lines do contact
	good or broken.
The light beam appears gloomily.	Inspect the optics part is whether clean.

Note: Other maintain work should by the specialist which has the experience to carry on.

### 8. Declaration

Before delivery, this fixture have the performance intact, packaging integrity, and all users should strictly observe the above warnings and operating instructions for the matter, with any damage caused by misuse is not guaranteed within the company, for damages caused by ignoring the manual instruction is not within the scope of the distributors or dealers. Thank you for your cooperation!

## 9. Equipment and appendix

1.	Led moving head light1pcs
2.	The Product of Instruction1pcs
3.	Power Cable1pcs
4.	XLR connector1unit
5.	Bracket1pcs
6.	M6 mm Screw2pcs

# 10. Menu display function

